

*Contatori Acqua - Water Meters***Descrizione:**

Utilizzando questo dispositivo è possibile totalizzare fino a 4 contatori per acqua con dispositivo lancia impulsi.

**Specifiche tecniche:**

Numero di ingressi a impulsi	Fino a 4
Lettura massima	1999.999 m <sup>3</sup>
Impulsi settabili	1, 2.5, 10, 25, 100, 1000 dm <sup>3</sup> /impulso
Fissaggio a muro	2 viti da Ø6
Alimentazione elettrica	Batteria iterna al litio (durata 8 anni)
Dimensioni	89x73x42 mm
Protezione IP	IP54



## Manuale Utente

Il totalizzatore H7-BM1 è equipaggiato con 3 pulsanti ed un display LCD.

Il pulsante K1 è posizionato all'esterno, vicino al display LCD.

I pulsanti K2 e K3 sono posizionati internamente, come mostra l'immagine sottostante.



Nel normale funzionamento, il tasto K1 serve a commutare la visualizzazione del display su un altro canale.

### Impostare il valore dell'impulso in entrata

- Alla pressione del tasto K2, il display mostra il valore di impulso corrente in entrata.
- E' possibile modificare i valori dell'impulso in entrata premendo il tasto K3
- Per impostare il valore, premere il tasto K2 o attendere qualche secondo.

### Impostare il valore iniziale di lettura

- Con il tasto K1, selezionare il canale desiderato.
- Mentre è visualizzato il numero del canale, premere il tasto K2. In questo modo il numero che indica la quantità di litri inizierà a lampeggiare.
- Premere il tasto K3 per impostare il valore desiderato (Impostare 0 per l'azzeramento). Premere il tasto K2 per spostarsi alla seconda posizione.
- Ripetere l'operazione per tutte le posizioni mostrate sul display. Alla pressione del tasto K2 nell'ultima posizione, i dati vengono memorizzati.

### Attenzione

É possibile impostare il valore iniziale di lettura solo dopo aver inizialmente impostato il valore dell'impulso in entrata.

*Contatori Acqua - Water Meters***Description:**

Use of this device allows totalizing and reading of the impulse signals generated by up to 4 water meters.

**Specifications:**

Impulse signals sources	Up to 4
Maximum reading value	1999.999 m <sup>3</sup>
Settable impulse values	1, 2.5, 10, 25, 100, 1000 dm <sup>3</sup> /pulse
Wall mounting	Using 2 screws Ø6
Power supply	Internal lithium battery (8 years life)
External dimensions	89x73x42 mm
IP protection	IP54



## User manual

H7-BM1 is equipped with 3 buttons and LCD display.

K1 button is located externally near LCD display.

K2 and K3 buttons are located internally as showed in the following picture.



K1 button is used in normal operating mode, for switching the display view to another channel.

### Setting the pulse value

- Press the button K2, the display shows the current pulse value.
- It is possible to change the pulse value by pressing button K3.
- For setting the value you can press button K2 or wait a few seconds.

### Set the starting reading value

- Press button K1 for choosing the correct channel
- While the display show the channel number, press button K2. In this way the figure starts flashing indicating the quantity of liters.
- Press button K3 for setting the desired starting reading value (set 0 for zeroing). You can press button K2 for moving to the second position.
- Repeat the previous operation for all the positions showed on the display. After pressing button K2 on the last position, the reading value is stored.

### Attention

It is possible to set the starting reading value after having initially set the pulse rate.